

VUDams java requirements

Connecting device with VU-DAMS software:

Description

Java version 8 (update 261) causes a crash in the VU-DAMS software when connecting a VU-AMS device using serial cable (Alt+S). This problem is probably caused by (auto) updating the java installation by the user or by Windows OS.

Solution: - shut down VU-DAMS; - uninstall java; - download the java version that works with the VU-DAMS software: <http://www.vuams.nl/software/jre-windows-x64.exe>; - install this version of java by executing the downloaded “jre-windows-x64.exe”; - untick “Check for Updates Automatically” in the update tab of the java control panel; - start VU-DAMS; - connect using serial cable should work again.

VU-DAMS (re)installation:

Description:

After a fresh VU-DAMS install or a reinstall followed by a removal of the java installation, VU-DAMS will notify the user that java needs to be installed. By accepting (clicking “Yes” in the dialog), the java download and install functionality fails.

Solution: - download the java version that works with the VU-DAMS software: <http://www.vuams.nl/software/jre-windows-x64.exe>; - install this version of java by executing the downloaded “jre-windows-x64.exe”; - untick “Check for Updates Automatically” in the update tab of the java control panel; - start VU-DAMS; - VU-DAMS should now work without asking the user to install java

For mac

Java 8 for mac

Follow the link: [Click here](#)

For mac with homebrew:

Follow instructions in the link: [Click here](#)